




CANIK

TP9 SFX



CANIK TP9 SFX EXPLODED VIEW AND PARTS LIST

PATP002E-TP-9 SFX Grey Back Strap (SM)
PATP002F-TP-9 SFX Grey Back Strap (LG)
PATP003A-TP-9 SA/ V2/ SF/ SFX Back Strap Pin
PATP004A-TP-9 SFX Magazine Catch Set
PATP004B-TP-9 SFX Magazine Release Button Screw
PATP004C-TP-9 SFX Magazine Release Button Small
PATP004D-TP-9 SFX Magazine Release Button Medium
PATP004E-TP-9 SFX Magazine Release Button Large
PATP005-TP-9 All Models Magazine Catch Spring
PATP006-TP-9 All Models Locking Block
PATP007-TP-9 All Models Locking Lever
PATP008-TP-9 All Models Locking Lever Spring
PATP009-TP-9 All Models Take Down Catch
PATP010-TP-9 All Models Take Down Catch Piece
PATP011-TP-9 All Models Take Down Catch Pin
PATP012A-TP-9 SA/ V2/ SF/ SFX Locking Lever Pin
PATP013A-TP-9 SA/ V2/ SF/ SFX Trigger Pin
PATP014-TP-9 SA/ SF/ SFX Trigger
PATP015-TP-9 SA/ SF/ SFX Only Trigger Safety Lever
PATP015A-TP-9 SA/ SF/ SFX Only Trigger Safety Lever Pin
PATP016-TP-9 SA/ SF/ SFX Only Trigger Safety Lever Spring
PATP017A-TP-9 SFX Slide Stop Lever
PATP018-TP-9 All Models Slide Stop Spring
PATP019-TP-9 All Models Ejector
PATP019A-TP-9 All Models Ejector Assembly
(Schematic Parts #18-23,26)

PATP020-TP-9 All Models Sear
PATP021-TP-9 All Models Sear Spring
PATP022-TP-9 All Models Sear Pin
PATP023A-TP-9 SF/ SFX Sear Lever
PATP024-TP-9 All Models Sear Lever Spring
PATP025-TP-9 All Models Sear Lever Pin
PATP026-TP-9 All Models Ejector Pin
PATP027-TP-9 SA/ SF/ SFX Trigger Bar
PATP028-TP-9 SA/ SF/ SFX Trigger Spring
PATP029A-TP-9 SA/ SF/ SFX Trigger Bar Pin
PATP030C-TP-9 SFX Only Slide
PATP031-TP-9 SA/ SF/ SFX Firing Pin Block Spring
PATP032-TP-9 All Models Firing Pin Block
PATP033-TP-9 All Models Extractor Pin Spring
PATP034-TP-9 All Models Extractor Pin
PATP035-TP-9 All Models Extractor Spring
PATP036-TP-9 All Models Extractor
PATP037-TP-9 All Models Firing Pin Collet
PATP038-TP-9 All Models Firing Pin Return Spring
PATP039-TP-9 All Models Firing Pin
PATP039A-TP-9 All Models Firing Pin Assembly
(Schematic Parts #37-41)
PATP040-TP-9 All Models Firing Pin Spring
PATP041-TP-9 All Models Firing Pin Retainer
PATP044-TP-9 All Models Slide Retaining Plate

PATP045E-TP-9 SFX Only Rear Sight
PATP045F-TP-9 SFX Rear Sight Base
PATP045G-TP-9 SFX Rear Sight Base Screws (2)
PATP045H-TP-9 SFX RMR Mounting Plate #01
PATP045J-TP-9 SFX RMR Mounting Plate #02
PATP045K-TP-9 SFX RMR Mounting Plate #03
PATP045M-TP-9 SFX RMR Mounting Plate #04
PATP045N-TP-9 SFX Cocking Lever
PATP045P-TP-9 SFX Lock Washers (4)
PATP046B-TP-9 SFX Rear Sight Mounting Screw (1)
PATP047C-TP-9 SF/ SFX All Pistols V2 SA from Serial # Front Sight
PATP047D-TP-9 SFX Front Sight Fiber Optic Insert - Green
PATP047E-TP-9 SFX Front Sight Fiber Optic Insert - Red
PATP049D-TP-9 SFX Barrel 5"
PATP050D-TP-9 SFX Recoil Spring Guide Assembly
(Schematic Parts #50-52)
PATP050E-TP-9 SFX Recoil Spring Guide
PATP051A-TP-9 SFX Recoil Spring Guide Stop
PATP052-TP-9 All Models Recoil Spring
PATP053-TP-9 All Models Magazine Body
PATP054-TP-9 All Models Magazine Follower
PATP055-TP-9 All Models Magazine Spring
PATP056A-TP-9 SFX 20 Rd Floorplate Lock
PATP057C-TP-9 SFX Floorplate (Grey)